

FENCE INSTALLATION



The installation of a ECO-FENCING system is easy and straightforward. All our products are compatible with recognised building and fencing material. ECO-FENCING can be sawn and fixed using traditional methods. The following easy-to-understand picture guide provides a detailed summary of installation.

INSTALL TRADITIONALLY ...



Step 1

Dig a hole with a minimum depth of around 60cm (24")



Step 2

Place the post inside the hole, making sure it is straight, then add the concrete.



Step 3

Simply attach your gravel boards and wooden fence panel.



Use ECO Fencing gravel boards with existing concrete posts.



Create a complete fence with gravel boards.



Natural wood grain creates a modern look.

INSTALL USING A SUPASPIKE ...

supaspjke

Patent Number 0605710.3



Step 1

Place the Supaspjke in position. Drive the fins 10cm below the surface.



Step 2

Place the post over the top of the Supaspjke and screw into position.



Step 3

Simply attach your gravel boards and wooden fence panels.

SECURITY CLIP INSTALLATION GUIDE



[Download Installation PDF](#)